

2D Image Barcode Scanner User Manual



Factory Default

Version



V1.0

Interface



USB



Rs232



USB-COM

Scan Mode



Manual



Successive scanning



Auto-Conduction



Trigger command mode

Suffix Settings



*Enter



Enter and Line



TAB



None

Sleep time settings



*Sleep time ON



Sleep time OFF

Note: When "Sleep time On"selected, in Manual mode, scanner will enter sleep mode after 30S, can worked by press the key of scanner

Buzzer



*Sound ON



Sound OFF



High



*Mid



Low

USB Country Keyboard types



*USA



Czech



Franch



German



Hungary



Italy



Janpan



Spain

Image Reverse



ON



OFF

Custom prefix Prefix Settings



Add prefix



*Delete Prefix



Modify prefix

Scan "Modify prefix", and data code, the user can modify the prefix content

Custom prefix Suffix Setting



Add Suffix



*Delete Suffix



Modify Suffix

Scan "Modify Suffix" and scan data code, user can modify the suffix content

Output Data Coding mode

In order to allow the host to print Chinese data in the specified encoding format, Can be set by reading the output data encoding format

Note: GBK format can be used for notepad, UNICODE format can be used WORD and chat tools commonly used input box, BIG5 format support traditional Chinese



*Output GBK type



Output UNICODE type



Output BIG5 type



Output UTF-8 type

Input Data Encoding mode

In order to allow the scanner to read a variety of encoding formats, Bar code can be read by the "input data encoding format" to set up



*Input GBK type



Input UNICODE type



Input AUTO type



Input UTF-8 type

Baud



4800



9600



19200



38400



57600



115200

Number Appendix



0



1



2



3



4



5



6



7



8



9



A



B



C



D



E



F



Save



Cancel one data before read



Cancel a string of data before read



Cancel Settings