

The right product for your great idea!

622 2D Image Barcode Scanner User Manual

Version 1.60, Jan.2018

Catalogue

catalogue	
catalogue form	
1 Start	¡Error! Marcador no definido.
1.1 Introduction	¡Error! Marcador no definido.
1.2 About this manual	¡Error! Marcador no definido.
1.3 Connect the function base and PC.....	¡Error! Marcador no definido.
1.4 Setting 6266M	¡Error! Marcador no definido.
1.4.1 Set code switch	¡Error! Marcador no definido.
1.4.2 Factory Default	¡Error! Marcador no definido.
1.4.3 User Default Settings	¡Error! Marcador no definido.
2 Communication Interface	¡Error! Marcador no definido.
2.1.1 RS232 Communication interface	
2.11 RS232 bit configuration	¡Error! Marcador no definido.
2.1.2 RS232 and Full Code Open Quick	¡Error! Marcador no definido.
2.2 USBHID interface	
2.21 HID devices selection	6
2.22 HID parameter configuration	21
2.23 HID leading key output	21
2.24 HID KBW and RS232output	21
2.3 USB-Com	8
3 Scan mode	¡Error! Marcador no definido.
3.1 Manual	¡Error! Marcador no definido.
3.2 Successive Scanning.....	¡Error! Marcador no definido.
3.3 Auto-Conduction	¡Error! Marcador no definido.
3.4 Trigger command mode	¡Error! Marcador no definido.
3.5 Pos Mode	29
4 Reading area	¡Error! Marcador no definido.
4.1 Full width area	¡Error! Marcador no definido.
4.2 Center area only.....	¡Error! Marcador no definido.
5 Lighting and aiming	¡Error! Marcador no definido.
5.1 Lighting	¡Error! Marcador no definido.
5.2 aiming	¡Error! Marcador no definido.
6 prompt output	¡Error! Marcador no definido.
6.1 All beeps	¡Error! Marcador no definido.
6.2the success tone of reading	¡Error! Marcador no definido.
6.3 Data Encoding Format	¡Error! Marcador no definido.
6.4 keyboard settings in all countries	¡Error! Marcador no definido.
6.5 Virtual Keyboard Enable	¡Error! Marcador no definido.

6.6	Invoice Mode Enable	¡Error! Marcador no definido.
6.7	Image Reverse.....	¡Error! Marcador no definido.
6.8	black and white reverse	¡Error! Marcador no definido.
6.9	Reading Version Information	¡Error! Marcador no definido.
6.10	Reading unique ID of device	¡Error! Marcador no definido.
7	Data Editing	¡Error! Marcador no definido.
7.1	Prefix	¡Error! Marcador no definido.
7.2	Suffix	¡Error! Marcador no definido.
7.3	CODE ID.....	27
7.4	Terminator	¡Error! Marcador no definido.
7.5	Data section interception	¡Error! Marcador no definido.
7.6	RF Information	¡Error! Marcador no definido.
7.7	Output agreement	¡Error! Marcador no definido.
7.8	UPCA convert to EAN 13	46
7.9	Product Code verification output enable	46
8	Barcode Type Enable / Disable Configuration	¡Error! Marcador no definido.
8.1	All bar codes can be solved.....	¡Error! Marcador no definido.
8.2	Readability	¡Error! Marcador no definido.
8.3	EAN13	34
8.4	EAN8	35
8.5	UPCA	36
8.6	UPCE0	36
8.7	UPCE1	37
8.8	Code128.....	37
8.9	Code39.....	38
8.10	Code93.....	39
8.11	CodeBar	40
8.12	QR	40
8.13	Interleaved 2 of 5	41
8.14	Industrial 25.....	42
8.15	Matrix 2 of 5.....	42
8.16	Code11.....	43
8.17	MSI	44
8.18	RSS	45
8.19	DM	45
8.20	PDF417.....	47
9	Appendix A: Default Settings Table.....	¡Error! Marcador no definido.
10	Appendix B: Common RS232 command	¡Error! Marcador no definido.
11	Appendix C: Code ID List.....	¡Error! Marcador no definido.
12	Appendix D: ASCII Table.....	¡Error! Marcador no definido.
13	Appendix E: Data Code	¡Error! Marcador no definido.
14	Appendix F: Save or Cancel	¡Error! Marcador no definido.

Catalogue Form

Form 1-1 flag list	¡Error! Marcador no definido.
Form 2-1 default RS232 communication parameters	4
Form 9-1 Default Settings Table	48
Form10-1 Common RS232 Interface Table	49
Form 11-1 Code ID List	50
Form 12-1 ASCII code table.....	51

1 Start

1.1 Introduction

6266M barcode reader, the application of the country's leading intelligent image recognition algorithm, and on this basis developed a set of advanced bar code reading algorithm, so as to realize the reading of smaller size, higher version of the bar code function

1.2 About this Manual

This manual mainly provides various function setting commands of 6266M reader. By familiarizing yourself with the introduction of various function commands in this manual, you can change the function parameters of 6266M, such as communication interface parameters, reading mode, prompt mode and so on. 6266M products have been shipped from the factory has been configured to fit most commonly used functions of the parameters, in most cases the user can make adjustments without adjustment can be used in the appendix of this manual, lists the default 6266M features and parameters for reference.


1.3 Barcode reading operation

6266M Thanks to the leading image recognition algorithm in the country and the barcode decoding algorithm developed on this basis, it is very easy and accurate to read barcode symbologies. Even if the bar code symbol at any rotation angle, will not affect the reading. In reading, the 6266M aimed at reading the bar code symbol can be.

1.4 Setting 6266M

1.41 Set Code Swith

By turning on the setting code function, the parameter setting of the reader can be performed by scanning the setting code.



1.42 Factory Default

By scanning the "Factory Default " barcode, all the reader parameters can be restored to the factory configuration



Factory Default

1.43 User default settings

In addition to the factory settings, the user can also save their frequently used configuration as the default settings of the user, and save the current configuration information of the device as the default setting information of the user by scanning "Save current setting as user default setting". If the reader The user has the default setting information, the new configuration information after the operation will replace the original user default setting information.

By scanning "restore user default settings" can be changed to the reader user default setting information



Save current settings as user defaults



Restore User default settings

2 Interface

6266M reader provides TTL-232 serial communication interface to communicate with the host. Through the communication interface, you can receive the read data, send commands to the reader to control, and change the reader's function parameters.

2.1 串行通讯接口 RS232 Communication Interface

Serial communication interface is a common way to connect the reader with the host device (such as PC, POS, etc.). When the reader and the host using a serial cable connection, the system uses serial communication mode by default. The use of serial communication interface, the reader and the host device must be in the communication parameters on the configuration to match, in order to ensure smooth communication and content is correct.



串口输出 (Serial output)


The reader's serial communication interface uses the TTL-level signal (TTL-232), which adapts to most system architectures. If the system requires the use of RS-232 form of the structure, the need to increase the external conversion circuit.

The default serial communication parameters of the reader are shown in Table 2-1. Among them, the baud rate of the reader can be modified through the serial port command, but the remaining parameters can not be modified.

Form 2-1 Default serial communication parameters

参数parameter	默认default
Serial communication type	Standard TTL-232
Baud rate	9600
check	not
Data bit	8
Stop bit	1
Hardware flow control	Not

Baud rate setting



2.1.1 RS232 bit configuration

Customers can modify the serial parity by scanning the following configuration code.



2.1.2 Rs232 and full-code open quick configuration

In order to help customers quickly configure the serial port and full-code open mode during secondary development, quick configuration function can be realized by scanning the following configuration codes.



串口&全码开启Serial & Full open

2.2 USB HID Interface

When the reader module is connected to the host using a USB cable, the reader module can be configured as a HID device by scanning the following setup code.

(USB HID device)



2.21 When the device is used as a HID device, it can be 2 different devices. Configure the following settings.




2.22 HID parameter configuration .

You can also modify the PC's access cycle to the HID device by scanning the following setup code.



*1ms



3ms



5ms



10ms

You can also modify the interval between valid message and release message of the device by scanning the following setting codes.



*0ms




1ms



5ms



10ms



15ms

You can also modify the interval between the device to release the packet and the next valid packet by scanning the following setting code.




0ms

*1ms



5ms



10ms



15ms

You can also modify the status of the CapsLock on output by scanning the following setup code.



*Off



On

2.23 HID leading key output

Users can scan the following configuration code to output a preamble message before outputting each piece of data from HID, which is convenient for customer software development and positioning.

The key value is ctrl+shift+r



HID disable

HID enable



2.24 HID KBW and RS232 output

The user can scan the following configuration code to enable data output through the serial port while HIDKBW is output.



Disable



enable

2.3 USB -COM

When the 6266M is connected with the host using the USB cable, the module can be configured as a virtual serial port output mode by scanning the USB virtual serial port setting code.



USB-COM

3 Scan mode (reading mode)

3.1 Manual

Manual reading mode is the default reading mode. In this mode, the 6266M starts reading the code after pressing the trigger key, and stops the reading after the reading code successfully outputs the message or releases the trigger key.



***Manual**

In this mode, 6266M default idle for a certain period of time, automatically enter the deep sleep mode, can be set by the following setup code.



Sleep time On



***Sleep time OFF**

After entering sleep mode, wake up by pressing the key, the device will reboot after exiting sleep mode.

In addition, when deep sleep is not enabled, you can also set the light sleep idle time by scanning the following setting codes.



0ms



***500ms**



3000ms



5000ms

3.2 Successive scanning mode

After setting, without trigger, 6266M reader immediately start reading, reading code successfully output information or single reading time after the end, 6266M wait for a period of time (can be set) will automatically start the next reading. If the following conditions do not occur, 6266M reader will work in the above cycle: During reading the user can also click the trigger button to manually pause the reading. Click the trigger button 6266M will continue to cycle reading.



Successive Scanning mode

Single reading time

In continuous reading mode, this parameter refers to the reading before the success of 6266M reader to allow continued recognition of the maximum acquisition time. After a successful reading or a single reading time-out, the 6266M reader enters the interval of not acquiring readings. Single reading time length setting range of 0.1 ~ 25.5 seconds, step 0.1 seconds; when set to 0, said the reading time unlimited. The default duration is 5.0 seconds.



1000ms



3000ms



***5000ms**



无限长

Reading interval length

This parameter refers to the interval between two adjacent readings, that is, after finishing the last reading of the reader (no matter the reading is successful or not), the reading will not be carried out within the set interval, until the interval ends After reading the next code. The reading interval setting range is from 0 to 25.5 seconds in 0.1 second steps. The default interval is 1.0 second.



无间隔

500ms

*1000ms



1500ms

2000ms

The same bar code reading delay

in order to prevent the same code from being read multiple times in succession, the reader can be asked to read the same code if it can not read the same code continuously for a period of time in this mode.

The same barcode reading delay means that the reader will read the same barcode and compare with the last reading time. When the interval time is longer than the reading delay time, the same barcode is allowed to be read out, otherwise the output is not allowed.



the same bar code reading delay

*The same bar code reading is not extended

The same barcode reading delay time

After enabling the same barcode reading delay, the same barcode reading delay time can be set through the following setting codes



Unlimited delay

500ms

1000ms



3000ms

5000ms

3.3 Autosensing Mode

After setting, without trigger, the reader immediately began to monitor the brightness of the surrounding environment, when the scene changes, the reader waits for the set of image stabilization time after the end of reading. After reading the successful output of information or single reading time-out after the reader to be some time interval (can be set) to re-enter the monitoring state. If the following conditions do not occur, the reader will cycle in the above way: In a single reading time bar code is not

scanned, the reader will automatically pause reading and into the monitoring state. In the inductive reading mode, the reader can also start reading the code after pressing the trigger key, and continue to monitor the brightness of the surrounding environment when the reading code successfully outputs the message or release the trigger key.



Autosensing mode

Single reading time

In inductive reading mode, this parameter refers to the maximum length of time that the reader will be allowed to continue acquisition recognition before the reading is successful. After a successful reading or a single reading timeout, the reader will enter the interval of not acquiring readings. Single reading time length setting range of 0.1 ~ 25.5 seconds, step 0.1 seconds. When set to 0, the reading time is infinite. The default duration is 5.0 seconds



1000ms



3000ms



*5000ms



无限长

Reading interval length

After reading the successful output of information or single reading time-out, the reader needs to be some time (can be set) to re-enter the monitoring state. The reading interval setting range is from 0 to 25.5 seconds in 0.1 second steps. The default interval is 1.0 second.



No Interval



500ms



*1000ms



1500ms

2000ms

Stable time

Stabilization time length refers to the sensor reading mode, detect the scene changes in the reader before reading the picture need to wait for the image stabilization time. Stabilization duration is set from 0 to 25.5 seconds in 0.1 second steps. The default image duration is 0.4 seconds.



100ms



***400ms**



1000ms



2000ms

Sensitivity

Sensitivity refers to the degree of change of the scene detected in the sense reading mode. When the reader to determine the degree of change in the scene to meet the requirements, will switch from monitoring status to read status.



***Normal sensitivity**



***Low Sensitivity**



High sensitivity



Very high sensitivity

The same bar code reading delay

It is not avoided that the same code is read consecutively multiple times, and the reader may be required to read the same code if it can not read the same code continuously for a period of time in this mode. Set code and continuous mode the same.

3.4 Command Trigger mode

In this mode, the reader starts to read the code when it receives the scan command sent by the host (ie bit0 of flag 0x0002 is written to "1"), and stops reading after the reading succeeds in outputting the message or the reading time of single reading .



command trigger mode

Note: In the command triggering mode, the serial port triggering the scan command is: 7E 00 08 01 00 02 01 AB CD; Upon receiving the trigger command, the reader will output seven bytes of response message and start the scan synchronously Information content: 02 00 00 01 00 33 31)

Single reading time

In command triggered reading mode, this parameter refers to the maximum length of time that the reader is allowed to continue acquisition recognition before the reading is successful. Single reading time length setting range of 0.1 ~ 25.5 seconds, step 0.1 seconds. When set to 0, the reading time is infinite. The default duration is 5.0 seconds.



1000ms



3000ms



*5000ms



Infinitely long

3.5 POS mode

The user can quickly configure the module to work in the POS mode by scanning the following setting code, including the following main features:

- 1: Read mode is command trigger mode;
- 2: The communication interface is RS232 ;
- 3: Turn off the start tone;
- 4: Close the end terminator;



POS Mode

4 Reading area

For different applications, users need to identify the area there will be some differences, by scanning the following setting code can be set.

4.1 Full area

When the reading area is full area, the reader will scan the barcode with the center as the priority, and the barcode may be anywhere on the screen.



***Full area**

4.2 Only the center area


When the reading area is the center area, the center position of the barcode must be within the set center area, and the bar codes that are not in the area are not recognized and output.



only the center area

Set the center area size:

The center area is an area centered on the whole image center. The size of the area is set in proportion to the width or height of the entire image, ranging from 1 to 100. If the setting value is 20, that is, Located in a center area of 20% of the width of a 20% height area.



Modify the center area size

Commonly used center area size can be set by scanning the following setting code:



Center area -20%



Center area -40%



center area -60%

When the size of the commonly used central area does not meet the needs, the user can also customize the configuration by scanning the "edit center area size" setting code.



Modify the center area size

Example:modify the 50% center area size

1. Check the character table to get "50" four characters hexadecimal value: "32"
2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)
3. Scan "Modify center area size" setting code
4. Scan the data setting code "3", "2" (see appendix E)
5. Scan "save" setting code (see Appendix F)

5 Lighting and aiming

5.1 Lingting

Lighting for shooting photography to provide auxiliary lighting, beam exposure to the reading target, to improve reading performance and adaptability to weak ambient light. The user can set it to one of the following depending on the application environment:

Normal (default setting): The light is on when taking a picture, and off at other times.

Always: The light is on after the module is switched on.

No lighting :The lighting does not illuminate under any circumstances.



***Normal**



Always



No lighting

5.2 Aiming

The aiming beam projected by the 6266M helps you find the best reading distance while shooting. Users can choose any of the following modes depending on the application environment.

Normal (default setting): The reader projects the aiming beam only during photographing.

Steady on: After the reader is powered on, it continuously projects the aiming beam.

None Aiming: In any case, the aiming beam is extinguished.



***Normal**



Steady on



None Aiming

6 prompt output

6.1 All beeps

Reading "Buzzer Drive Frequency" sets the buzzer to active / passive buzzer, and also sets the drive frequency of passive buzzer.



Buzzer drive frequency - passive low frequency



Buzzer drive frequency - passive IF



Buzzer drive frequency - passive high frequency



Buzzer drive frequency - active drive

In active buzzer mode, reading "buzzer working level - high" can be set as buzzer idle low level, working high level; buzzer working level - low "can be set as buzzer Idle idle high, working low.



*** Buzzer working level - high**



Buzzer working level - low

Read "Start Mute" to turn off all beeps. Read "Turn off mute" to cancel the mute setting.



On



***Off**

6.2 read the success tone

Read the "turn off decoding success tone" can prohibit barcode reading successful voice prompts, read "open the decoding success tone" to restore the barcode reading success prompts.



***Turn on reading success tone**



Turn off reading success tone

60ms Reading the Tone Duration sets the duration for reading the success tone. Default 60ms



Prompt tone duration -30ms



***Prompt tone duration -60ms**



Prompt tone duration -90ms



Prompt tone duration -120ms

6.3 Data encoding format

In order for the reader to read Chinese bar codes of various encoding formats, it can be set by reading the "Input Data Encoding Format".



*** Input data encoding format GBK**



Input data encoding format UTF8



Input data encoding format AUTO

In order for the host computer to print Chinese data in the specified encoding format, it can be set by reading "Output Data Encoding Format".

Note: GBK format can be used for Notepad, UNICODE format can be used for WORD and common chat tool input box.



*Output data encoding format GBK



Output data encoding format UNICODE



Output data encoding format UTF8

6.4 national keyboard settings

In order for the hosts in all countries to use the device, they can be set by reading the "keyboard" of the corresponding country.



* Keyboard - United States



Czech Republic



France



German



Hungary



Italy



Japan



Spain



Turkey




6.5 Virtual Keyboard Enable

In order to be able to use more areas, we also provide a virtual keyboard function, enable the virtual keyboard, you can output in any keyboard mode, but the relative loss of a certain output efficiency. Also, when using a virtual keyboard, you must make sure the keypad numeric keys are enabled. Note that the virtual keyboard must be available in versions 1.21 and later.



*Standard keyboard



virtual keyboard

6.6 Invoice mode is enabled

In order to use this module normally in the billing system, the user can convert the format of the invoice code and output it by scanning the following configuration codes



*Invoice mode is disabled



Invoice mode is enabled

6.7 image flip

In practice, we encounter a mirror image or vertical flip image, as shown below

F

Ǝ

原始图像

镜像翻转

When the bar code appears flip, you can enter the mirror flip mode by scanning the corresponding setting code



进入镜像翻转模式(Enter)



*退出镜像翻转模式 (return)

Note: In Mirror Flip mode, only the mirror with inverted image can be identified. If you need to identify the normal barcode or setup code, please exit Mirror Flip mode first.

6.8 black and white flip

In some special scenes, the black and white of the barcode may be reversed. By scanning the following setting codes, the module can be configured to recognize both normal and anti-colored barcodes.



* One-dimensional bar code can disable anti-color decoding One-dimensional bar codes enable inverse color decoding



*two-dimensional bar code can disable anti-color decoding

One-dimensional bar codes enable
inverse color decoding

6.9 Read the Version Information

In order for the host to quickly read the current version of the device information, you can "read version information" to confirm



The code of reading the version information

6.10 Reading unique ID of device

In order to obtain the device's unique ID, you can confirm it with the "Read Device Unique ID" barcode



Read device unique ID

7 Data editing

In practice, sometimes we need to edit the data after reading and then output, to facilitate data differentiation and processing.

Data editing includes:

- Increase Prefix
- Increase Suffix
- decoding information Data section interception
- output barcode type CodeID
- Decoding failed to output specific RF
- Increase the terminal Tail

The processed data default output sequence is as follows:

【Prefix】 【CodeID】 【Data】 【Suffix】 【Tail】

7.1 Prefix

Increase the Prefix

The prefix is a string that is customized and modified by the user before decoding information. It can be added by scanning the "Add prefix" setting code.



Allow to increase prefix



not allow to increase prefix

Modify the prefix

Scan "modify prefix" setting code, and combine scan data setting code, users can modify the prefix content, use two hexadecimal values for each prefix character, the prefix allows up to 15 characters, hexadecimal conversion table of character value Please refer to Appendix D. Scan "modify prefix" setting code, and combine scan data setting code, users can modify the prefix content, use two hexadecimal values for each prefix character, the prefix allows up to 15 characters, hexadecimal conversion table of character value Please refer to Appendix D.



Modify the code

Example: Modify user-defined prefix "DATA"

1. Check the character table to get "DATA" four characters hexadecimal value: "44", "41", "54", "41"
2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)
3. Scan the "Modify prefix" setting code
4. “4” 、 “4” 、 “4” 、 “1” 、 “5” 、 “4” 、 “4” 、 “1” Scan the data setting codes "4", "4", "4", "1", "5", "4", "4", "1"
5. Scan "save" setting code

7.2 Suffix

Add a suffix

The suffix is a string that is customized and modified by the user after the information is decoded, and can be added by scanning the "allow suffix" setting code



Allow to add a suffix



***not allow to add a suffix**

Modify the suffix

Scan the "Modify Suffix" setting code, and set the scan data setting code, the user can modify the suffix content, use two hexadecimal values for each suffix character, suffix up to 15 characters, character value hexadecimal conversion table Please refer to Appendix D.



Modify the suffix

Example: Modify user-defined suffix "DATA"

1. Check the character table to get "DATA" four characters hexadecimal value: "44", "41", "54", "41"

2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)
3. Scan the "Modify Suffix" setting code
4. Scan the data setting codes "4", "4", "4", "1", "5", "4", "4", "1"
5. Scan "save" setting code

7.3 CODE ID

Add CODE ID

Users can use CODE ID to identify different barcode types. The CODE ID corresponding to each barcode type can be freely modified. The CODE ID is identified by a single character.



Allow to add CODE ID



*not allow to add CODE ID

CODE ID default value

Scan the "CODE ID default" setting code, each bar code corresponding to the CODE ID can be restored to the default value, the default CODE ID can refer to Appendix C



The default CODE ID for all bar codes

Modify the CODE ID

the CODE ID corresponding to each barcode can be freely modified by scanning the corresponding setting code and combining the scan data setting code. CODE ID characters corresponding to each bar code using a hexadecimal value that the character value of the hexadecimal conversion table can refer to Appendix D

Example: CODE 128 code corresponding to modify the CODE ID "A"

1. Check the character table to get the "A" character hexadecimal value: "41"
2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)
3. Scan the "Change CODE ID of CODE 128" setting code
4. Scan the data setting code "4", "1"

5. Scan "save" setting code

Modify each barcode type CODE ID setting code list:



Modify the CODE ID of EAN13



EAN8's CODE ID



Modify UPCA's CODE ID



UPCE0 CODE ID



Modify UPCE1's CODE ID



Change Code 128 Code ID



修改CODE 39的CODE ID



修改CODE 93的CODE ID



Change CODE ID of CODE BAR



Change the CODE ID for Interleaved 2 of 5



Modify Industrial 25 CODE ID



Modify the Matrix 2 of 5 CODE ID



Change CODE 11 CODE ID



修改MSI的CODE ID



Modify the RSS CODE ID



Modify the CODE ID for the restricted RSS



Modify the extended RSS CODE ID



Modify QR CODE's CODE ID



Modify the Data Matrix CODE ID



Modify the CODE ID of the Limited PDF417

7.4 terminator

To enable the host to quickly distinguish between the results of the current decoding, you can turn this feature on.

Read "add terminator" When this function is enabled, if the reading is successful, the reader adds the corresponding terminator after decoding the data



Close the ending character



*Add terminator CR



Increase the ending character TAB

Add terminator CRLF

7.5 Data section interception

When users only need to output part of the decoding information, you can turn on this feature.

We will decode the information [Data] is divided into three parts:

【Start】 【Center】 【End】

The Start, End section of the character length can be controlled by scanning code.

The user sets the code by scanning the code below, you can choose to output the corresponding position of the decoding information.



***Transfer the entire Data section**



Only the Start segment is transmitted



Only the End segment is transmitted



Only the center segment is transmitted

Modify the length of the Start section M

The length of the Start section can be modified by scanning the "Intercepting length before modification" M and setting the length of the Start section. The maximum length of the Start section is 255 characters. The length of the front section M is represented by a hexadecimal character, and the length M is ten Refer to Appendix D for hex value conversion table.



Modify the length of the Start section M

Modify the length of End section N

Scan the "modified interception length N", and set the scan data setting code, you can modify the length of the End section, End section allows up to 255 characters, the interception length N using a hexadecimal character, the length N corresponding to ten Refer to Appendix D for hex value conversion

table.



Modify the length of End section N

Only the Start segment is transmitted

Example: When the decoding information is "1234567890123ABC", the first 13 bytes "1234567890123"

1. Check the character table to get the decimal data "13" corresponds to the hexadecimal character "0D"
2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)
3. Scan the "Pre-modification length M" setting code
4. Scan the data setting code "0", "D"
5. Scan "save" setting code
6. Scan the "Start only transfer" setting code

Only the End segment is transmitted

Example: When the decoding information is "1234567890123ABC", the last three bytes "ABC"

1. Check the character table to get the decimal data "3" corresponds to the hexadecimal character "03"
2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)
3. Scan "modified cut length N" setting code
4. Scan data setting code "0", "3"
5. Scan "save" setting code
6. Scan "End segment only" setting code

Only the Center section is transmitted

Example: When the decoding information is "12345678900123ABC", the middle four bytes "0123"

1. Check the character table to get the decimal data "10", "3" corresponds to the hexadecimal characters were "0A", "03"

2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)

3. Scan "modified cut length N" setting code
4. Scan data setting code "0", "3"
5. Scan "save" setting code
6. Scan "modify before cut length M" setting code
7. Scan the data setting code "0", "A"
8. Scan the "Save" setting code
9. Scan the "Center section only" setting code

7.6 RF information

RF (Read Fail) message refers to the reader in some modes, you want to read the code is unsuccessful, the user output some information freely defined, the user or program detects this information and make the appropriate adjustments or operations



Send RF information



***not send RF information**

Modify RF information

Scan the "Modify RF Information" setting code, and combine the scan data setting code. The user can modify the RF information content, use two hexadecimal values for each RF character, RF up to 15 characters, hexadecimal Conversion table can refer to the appendix



Modify RF information

Example: Modify User Defined RF Information to "FAIL"

1. Check the character table to get "FAIL" four characters hexadecimal value: "46", "41", "49", "4C"
2. Check whether the setting code is on. If it is not on, please scan the setting code "on" (see section 1.5.2)

3. Scan "modify RF information" setting code

4. Scan the data setting codes "4", "6", "4", "1", "4", "9", "4", "C"

5. Scan "save" setting code

7.7 Output protocol

The following setting code can be used to modify the output format of the decoding result in serial / virtual serial port mode by scanning.

The format of the output with protocol is selected as follows: <03> <Length> <Decode Data>.

In addition, when the output with protocol is enabled in serial / virtual serial port mode, the module will not add an ending character to the decoded data.



*Pure data



With agreement

7.8 UPCA convert to EAN 13

You can enable or disable UPCA conversion to EAN13 by scanning the following setting code



Enable




Disable

7.9 Product code verification output enable

The output of the product code parity bit (including EAN8/EAN13/UPCE0/UPCE1/UPCA) can be enabled by scanning the following setting code

Enable



Disable



8 barcode type enable / disable configuration

8.1 All bar codes are solvable

Read the following setting code, all supported bar code types will be allowed or not to be read.
After all types are forbidden, only setting code can be read



All types are allowed to be read



Prohibition of reading all types



*Open the default type of reading

8.2 Readability

By enabling the bar code reading capability enhancement, the reading angle of all bar codes will be improved, the device's support for angles above 45° will be improved, and the support for low contrast and gradient codes will be improved. Forbidding angle enhancement will increase decoding speed.



* Diable



Enable

8.3 EAN13

Read the following setting code, will EAN13 bar code to allow / prohibit reading set



***Allow to read EAN13**

Not allow to read EAN13

Read the following setting code, you can configure EAN13 additional code reading is enabled or disabled



***2 additional code can be disabled**



2 additional code can be enabled



***5 additional code can be disabled**



5additional code can be disabled

8.4 EAN8

Read the following setting code, will be EAN8 bar code to allow / prohibit read set



***Allow to read EAN8**



EAN8Prohibition of reading EAN8

Read the following setting code, you can configure EAN13 additional code reading is enabled or disabled



***2 additional code can be disabled**



2 additional code can be enabled



* 5 additional code can be disabled



5 additional code can be enabled

8.5 UPCA

Read the following setting code to set UPCA bar code enable / disable reading




***Allow to read UPCA**



not allow to read UPCA

Read the following setting code, you can configure the UPCA additional code reading is enabled or disabled



***2 additional code can be disabled**



2 additional code is enable



***5 additional code can be disabled**



5 additional code is enabled

8.6 UPCE0

Read the following setting code, set UPCE0 bar code enable / disable reading



***Allow to read UPCE0**



Not allow to read UPCE0

8.7 UPCE1

Read the following setting code, set UPCE1 bar code to enable / disable reading



***Allow to read UPCE1**



Not allow to read UPCE1

Read the following setting code, you can configure UPC-E1 additional code reading is enabled or disabled



***2 additional code can be disabled**



2 additional code is enabled



*** 5-digit additional code can be disabled**



5 additional code is enabled

8.8 Code128

Read the following setting code, Code128 bar code to enable / disable the reading to be set



***Allow to read Code128**

Not allow to read Code128

Read the following setting code, will be the shortest reading length of Code128 bar code set



The minimum length of Code128 information is 0

***The minimum length of code is 4**

Read the following setting code, the maximum length of Code128 bar code to read set



*** The maximum length of Code128 information is 32**

The maximum length of Code128 information is 255

8.9 Code39

Read the following setting code, Code39 bar code to enable / disable the reading to be set



*** Allow to read Code39**

Not allow to read code 39

Read the following setting code, Code39 bar code will be the shortest length of reading set



Code39 minimum length of information is 0

***Code39 minimum length of information is 4**

Read the following setting code, will set the longest reading length of Code39 bar code.



*** Code39 maximum length of 32**

The maximum length of Code39 information is 255

Read the following setting code, you can configure Code39 whether to support Code32 mode and FullAsc mode.




***Code32 is not enabled**



Enable Code32



***Does not enable FullAsc mode**



Enable FullAsc mode

8.10 Code93

Read the following setting code, will Code93 bar code to allow / prohibit reading set.



***Allow to read code 93**



Code93Not allow to read 93

Read the following setting code, the Code93 bar code will be the shortest length of reading set.



The minimum length of Code93 is 0



***Code93 minimum length of 4**

Code93 bar code will be the longest length of reading set.



*** Code93 maximum length of 32**



The maximum length of Code93 is 255

8.11 CodeBar

Read the following setting code, CodeBar bar code to enable / disable the reading set.



***Allow to read CodeBar**



Not allow to read CodeBar

Read the following setting code, the CodeBar bar code to allow / prohibit to send start and stop set.



Send CodeBar start and end



***Does not send CodeBar start and end breaks**

Read the following setting code, set the minimum length of CodeBar reader.



The minimum length of CodeBar information is 0 *The minimum length of CodeBar information is 4



Read the following setting code, will set the maximum length of CodeBar barcode reader.



***The maximum length of CodeBar information is 32 The maximum length of a CodeBar message is 255**



8.12 QR

Read the following setting code, will be set to enable / disable QR barcode reading.



***QRAllow to read QR**



Not allow to read QR

8.13 Interleaved 2 of 5

Read the following setting codes to set the Interleaved 2 of 5 bar code enable / disable reading.



Interleaved 2 of 5 is allowed

***Prohibition of reading Interleaved 2 of 5**

Read the following setting code, will set the minimum reading length of Interleaved 2 of 5 bar code.



Interleaved 2 of 5 The minimum length of the message is 0 * Interleaved 2 of 5 The minimum length of the message is 4

The following setting codes will be read to set the maximum reading length of Interleaved 2 of 5 barcode.



*** Interleaved 2 of 5 The maximum length of the message is 32** Interleaved 2 of 5 The maximum message length is 255

8.14 Industrial 25

The following setting codes will be read to set the Enable / Disable for Industrial 25 bar code reading.



Allow to read Industrial 25



***Not allow to read Industrial 25**

Read the following setting code, the Industrial 25 bar code to read the shortest length set.



Industrial 25 The minimum length is 0



***Industrial 25 The minimum length is 4**

The following setting codes will be read, and the longest reading length of Industrial 25 bar code will be set.



*** The maximum length of the information is 32**



The maximum length of the information is 255

8.15 Matrix 2 of 5

Read the following setting codes to set the Matrix 2 of 5 bar code enable / disable reading.



Allow to read Matrix 2 of 5



***Not allow to read Matrix 2 of 5**

Read the following setting codes to set the minimum reading length of Matrix 2 of 5 barcode.



The minimum length is 0



*The minimum length is 4

The following setting codes will be read to set the maximum reading length of Matrix 2 of 5 barcode.



* The maximum length is 32



The maximum length is 255

Read the following setting code, will set the Matrix2 of 5 bar code format.



parity format is Mod10



*Noneparity format is None

8.16 Code11

Read the following setting code, will Code11 bar code to allow / prohibit reading set.



Allow to read Code11



*Not allow to read Code11

Read the following setting code, the shortest length of Code11 bar code will be set.



Code 11 minimum length of information is 0



*Code 11 minimum length of information is 4

Read the following setting code, set the maximum length of Code11 barcode reader.



* Code11 maximum length of 32



255Code11 maximum length of 255

Read the following setting code, the Code11 calibration method will be configured.



Code11 using 1bit calibration



*Code11 using 1bit calibration

8.17 MSI

Read the following setting code, set the MSI bar code enable / disable reading.



Allow to read MSI



*Not allow to read MSI

Read the following setting code, set the minimum reading length of MSI bar code.



The minimum length of MSI information is 0



*The minimum length of MSI information is 4

Read the following setting code, set the longest reading length of MSI barcode.



* The maximum length of MSI information is 32



The maximum length of MSI information is 255

8.18 RSS

Read the following setting code, will be set to enable / disable RSS-14 bar code reading.



Allow to read RSS-14



***RSS-14 Prohibition of reading RSS-14**

Read the following setting code, will be limited RSS bar code to allow / prohibit reading set.



Allow to read RSS



Not allow to read RSS

Read the following setting code, will be extended RSS bar code to allow / prohibit read set.



Allow to read RSS



***Not allow to RSS**

Read the following setting code, set the minimum reading length of RSS barcode.



RSS message minimum length is 0



***minimum length is 4**

Read the following setting code, set the maximum length of RSS barcode reader.



*** The maximum length of RSS messages is 32**



The maximum length of RSS messages is 255

8.19 DM

Read the following setting code, DM bar code to enable / disable the read set.



***Allow to read DM**



Not allow to read DM

Read the following setting code, will set whether the module supports decoding multiple DM barcode at the same time.



***Do not read more than one DM barcode at the same time**

Allows multiple DM bar codes to be read simultaneously

8.20 PDF417

Read the following setting code, will be PDF417 bar code to allow / prohibit read set.



***Allow to read PDF417**



Not allow to read PDF417

9 Appendix A: Default Settings Table

Format 9-1 Default settings table

parameter name		default setting	Noted
Interface			
TTL-232	Baud rate	9600	
	Inspection	Not inspection	
	Data bit	8 bits	
	Stop bit	1 bit	
	Hardware flow control	Not	
Mode parameters			
The default mode of reading		Manual Mode	
Serial trigger mode	Single reading time	5s	Parameter range: 0.1-25.5 seconds, step is 0.1s; 0 means that the single decoding time is not limited
Manual Mode	Trigger level	Low trigger	The default high level

10 Appendix B: Common Serial Instructions

Form 10-1 Common serial instructions

Features	串口指令
Set the baud rate to 9600	7E 00 08 01 00 D9 D3 20 38
Save the settings to EEPROM	7E 00 09 01 00 00 DE C8
Query baud rate	7E 00 07 01 00 2A 02 D8 0F

After the host sends the serial port command to query the baud rate, the reading module will reply the following message:

returned messages	Corresponding baud rate
02 00 00 02 C4 09 SS SS	1200
02 00 00 02 71 02 SS SS	4800
02 00 00 02 39 01 SS SS	9600
02 00 00 02 D0 00 SS SS	14400
02 00 00 02 9C 00 SS SS	19200
02 00 00 02 4E 00 SS SS	38400
02 00 00 02 34 00 SS SS	57600

Note: SS SS is the calibration value.

11 Appendix C: List of Code IDs

form 11-1 Code ID list

Type of Bar code	Corresponding character	Flag address
EAN-13	d	0x91
EAN-8	d	0x92
UPC-A	c	0x93
UPC-E0	c	0x94
UPC-E1	c	0x95
Code 128	j	0x96
Code 39	b	0x97
Code 93	i	0x98
Codabar	a	0x99
Interleaved 2 of 5	e	0x9A
Industrial 2 of 5	D	0x9B
Matrix 2 of 5	v	0x9C
Code 11	H	0x9D
MSI-Plessey	m	0x9E
GS1 Databar(RSS-14)	R	0x9F
GS1 Databar Limited(RSS)	R	0xA0
GS1 Databar Expanded(RSS)	R	0xA1
QR Code	Q	0xA2
Data Matrix	u	0xA3
PDF 417	r	0xA4

12 Appendix D: ASCII Code Table

表 12-1 ASCII code table

Hexadecimal	Decimal	character
00	0	NUL
01	1	SOH
02	2	STX
03	3	ETX
04	4	EOT
05	5	ENQ
06	6	ACK
07	7	BEL
08	8	BS
09	9	HT
0a	10	LF
0b	11	VT
0c	12	FF
0d	13	CR
0e	14	SO
0f	15	SI
10	16	DLE
11	17	DC1
12	18	DC2
13	19	DC3
14	20	DC4
15	21	NAK
16	22	SYN
17	23	ETB
18	24	CAN
19	25	EM
1a	26	SUB
1b	27	ESC
1c	28	FS

Hexadecimal	Decimal	character
1d	29	GS
1e	30	RS
1f	31	US
20	32	SP
21	33	!
22	34	"
23	35	#
24	36	\$
25	37	%
26	38	&
27	39	`
28	40	(
29	41)
2a	42	*
2b	43	+
2c	44	,
2d	45	-
2e	46	.
2f	47	/
30	48	0
31	49	1
32	50	2
33	51	3
34	52	4
35	53	5
36	54	6
37	55	7
38	56	8
39	57	9
3a	58	:
3b	59	;
3c	60	<
3d	61	=
3e	62	>

Hexadecimal	Decimal	character
3f	63	?
40	64	@
41	65	A
42	66	B
43	67	C
44	68	D
45	69	E
46	70	F
47	71	G
48	72	H
49	73	I
4a	74	J
4b	75	K
4c	76	L
4d	77	M
4e	78	N
4f	79	O
50	80	P
51	81	Q
52	82	R
53	83	S
54	84	T
55	85	U
56	86	V
57	87	W
58	88	X
59	89	Y
5a	90	Z
5b	91	[
5c	92	\
5d	93]
5e	94	^
5f	95	_
60	96	'

Hexadecimal	Decimal	character
61	97	a
62	98	b
63	99	c
64	100	d
65	101	e
66	102	f
67	103	g
68	104	h
69	105	i
6a	106	j
6b	107	k
6c	108	l
6d	109	m
6e	110	n
6f	111	o
70	112	p
71	113	q
72	114	r
73	115	s
74	116	t
75	117	u
76	118	v
77	119	w
78	120	x
79	121	y
7a	122	z
7b	123	{
7c	124	
7d	125	}
7e	126	~
7f	127	DEL

13 Appendix E: Data Codes

0 ~ 9



A – F





C



D



E



F

14 Appendix F: Save or Cancel

After reading the data code to scan the "save" setting code to read the data saved. If you make a mistake while reading the data code, you can cancel reading the wrong data.

Such as reading a setting code and reading the data "A", "B", "C" and "D" in sequence, if "one data before last reading" is read, the last read The number "D" will cancel the read data "ABCD" if "Cancel a previous data string" is read, and cancel the read data "ABCD" if "Unchanged data setting" is read and exit the modification Set.



Save



Cancel the previous read a data



Cancel the previous read a bunch of data



Cancel to change the setting