

# MANUAL SCAN TLM-1010

## 1. Keyboard Language

In order to let scanner upload the codes in a correct way, you have to set the keyboard language.

For example If you use French Keyboard, scan below barcode of “French keyboard”. So the scanner can be able to upload barcodes according to French keyboard layout. American Keyboard is set by default, if you use a US keyboard you can ignore this part.



0005000

American Keyboard



0005012

Italy Keyboard



0005017

Portugal Keyboard



0005009

French Keyboard



0005020

Spanish Keyboard



0005010

Germany Keyboard



0005027

Turkey Q Keyboard

## 2. Scan Mode



013301

Key trigger (by default)



013304

Continuous Mode

## 3.Common Function Barcodes



0B

Default Setting

## 4. Beep Sound On/ Off



014200

Turn off the sound



0B142

Turn on the sound

## 5. Terminator Setting



0202011000\$0D

Suffix Character- CR



0202011000\$0A

Suffix Character- LF



0202011000\$0D\$0A

Suffix Character-CR+LF



0202011000\$09

Suffix Character- TAB



0B20201

Cancel Suffix Character

## 6. Function Setup Barcodes



01261

Enable Code 11



00221

Enable Code 39



00231

Enable Full ASCII



00261

Enable Code 32



00621

Enable Code 93



00691

Enable Code 128



01260

Disable Code 11



00220

Disable Code 39



00230

Disable Full ASCII



00260

Disable Code 32



00620

Disable Code 93



00690

Disable Code 128



00851

Enable Codabar



00961

Enable Interleaved 2 of 5



01061

Enable Industrial 2 of 5



01461

Enable Matrix 2 of 5



01151

Enable MSI



00341

Enable UPC-A



00351

Enable UPC-E



00361

Enable EAN-13



00371

Enable EAN-8



00850

Disable Codabar



00960

Disable Interleaved 2 of 5



01060

Disable Industrial 2 of 5



01460

Disable Matrix 2 of 5



01150

Disable MSI



00340

Disable UPC-A



00350

Disable UPC-E



00360

Disable EAN-13



00370

Disable EAN-8